



January 2011

Important Information

Introduction

Thank you for buying a light from Reclaimed Enjoyment. Please read through the manual thoroughly before plugging the light into the mains. If the light was damaged in transit, don't use it, and contact Reclaimed Enjoyment immediately.

WEEE

To all residents of the European Union
Important environmental information about this product



This symbol indicates that this product should be taken to a specialised company for recycling.

■ If in doubt, contact your local waste disposal authorities.

Safety Instructions



hot!

Be careful when changing the lamp in this light. Unplug the light from the mains before attempting to change the lamp. Remember the lamp may be



Be careful during use of the light as the housing heats up.

- This light is for indoor use only.
- Do not look directly into the light source as sensitive people may go into epileptic seizure if they do.
- Respect a minimum distance of 1m between the unit's light output and any illuminated surface.
- All modifications of the unit are forbidden for safety reasons, and will void any warranty.

Changing the lamp



Warning – only attempt to change the lamp when the light is unplugged from the mains.

- Let the lamp cool down before replacing it as the lamp will be very hot.
- When handling halogen lamps, do not touch it with your bare hands. Use a cloth to insert or remove it.
- Do not install lamps with a higher wattage. They will get hotter than this unit was designed for.
- Replace lamp with same type.

Do not operate this light when the cover is open.

Technical specifications

Power Supply	max.230VAC / 50-60Hz
Lamp Size	max 100W
Max. Ambient Temperature	45°C
Max Housing Temperature	100°C

The information in this manual is subject to change without prior notice.

©Reclaimed Enjoyment 2011
Restored Vintage Theatrical Lighting

95 Chesterfield Road, North Wingfield, Chesterfield, Derbyshire, S42 5LF
www.reclaimedenjoyment.co.uk